



BMP Objectives

- Soil Stabilization
- O Sediment Control
- Tracking Control
- Wind Erosion Control
- Non-Storm Water Management
- Materials and Waste Management

Definition and Purpose

Concrete finishing methods are used for bridge deck rehabilitation, paint removal, curing compound removal, and final surface finish appearances. Methods include sand blasting, shot blasting, grinding, or high pressure water blasting. Proper procedures minimize the impact that concrete finishing methods may have on runoff.

Appropriate Applications

These procedures apply to all construction locations where concrete finishing operations are performed.

Limitations

■ Specific permit requirements may be included in the contract documents for certain concrete finishing operations.

Standards and Specifications

- Follow containment requirements stated in the project special provisions, if any.
- Collect and properly dispose of water and solid waste from high-pressure water blasting operations.
- Collect water from blasting operations and transport or dispose of water in a non-erodible manner. Refer to BMPs SS-9, "Earth Dikes/Drainage Swales & Lined Ditches," SS-10, "Outlet Protection/Velocity Dissipation Devices," and SS-11, "Slope Drains."
- Direct water from blasting operations away from inlets and watercourses to collection areas for removal (e.g., dewatering) as approved in advance by the RE and in accordance with applicable permits.
- Protect inlets during sandblasting operations. Refer to BMP SC-10, "Storm Drain Inlet Protection."

Concrete Finishing

- Refer to BMP WM-8, "Concrete Waste Management."
- Minimize the drift of dust and blast material as much as possible by keeping the blasting nozzle close to the surface.
- When blast residue contains a potentially hazardous waste, refer to BMP WM-6, "Hazardous Waste Management."

Maintenance and Inspection

- Follow inspection procedure as required in the project special provisions.
- At a minimum, inspect containment structures, if any, for damage or voids prior to use each day and prior to the onset of rain.
- At the end of each work shift, remove and contain the liquid and solid wastes from containment structures, if any, and from the general work area.
- Discharges to waterways shall be reported to RE immediately upon discovery. A written discharge notification must follow within 7 days or as required by special provisions.